

Assembly Instructions

Set of TWO underdrawers

Fixings to assembly product



Fixing E
35mm silver Screw
Used to attach base slats

Number required **8**



Fixing L
Small silver 15mm screw
To connect fixing H & G

Number Required **32**



Caster Wheels

8



Fixing M

Number Required **8**

To ALL customers - If you have a missing or damaged bolt you can order these FREE of CHARGE using the following method, please note we will require your order number or delivery address
Telephone: 01767 682007
Email: help@strictlybedsandbunks.co.uk
Website: www.strictlyhelpdesk.co.uk
All fixings are sent out via next day Royal Mail Post

Packing Note: SET of TWO Under Drawers

Fixing Kit 17

SKU/Location	Description	Requirec
1PL R1G	Plywood Base	<input type="text" value="2"/>
4L R1H	Under Drawer Front Headboard	<input type="text" value="2"/>
C2B	Under Drawer Sides	<input type="text" value="4"/>
R1F	Underdrawer Back Headboard	<input type="text" value="2"/>
	FIXING KIT	<input type="text" value="1"/>



Place the drawer front face down on a carpeted floor. Important, the grooved edge must be facing you and at the bottom as per the picture.

Now get one of the sides, they are universal so any one will do. Again make sure the groove is at the bottom in line with the front of the drawer.

Now using the silver bolt E attach from the inside. Repeat for the other side.



Once you have attached both the sides slide in the plywood base. Once the base is in attach the back using the BLACK screws provided.



Now we need to fix the castor wheels to each corner. Using the small screw L attach each corner wheel. You will only be able to attach 3 screws per corner. This is sufficient to hold in place.



Note: END PANEL

Under drawers when purchased on their own do not come with an end panel. However if you have purchased a storage bed you will have an end panel. This is designed to go at the footboard end of the bed. The parcel will be marked E/P.

To fix this you simply loosen the two end corner posts. Push the end in from the end until fitting flush. Re-tighten the corner posts and attach the top of the end panel to the end fascia board.