

## Set of TWO underdrawers

### Fixings to assemble product



Black Castor Wheels

Number Required 8



Fixing Q  
Black screw (42mm)  
To attach drawer sides

Number Required 30



Fixing L  
Small silver 15mm screw  
To attach Castor wheels

Number Required

32

### Packing Note: SET of TWO Under Drawers

Description	Required
MDF BASE	<input type="text" value="2"/>
Under Drawer Front Headboard	<input type="text" value="2"/>
Under Drawer Sides	<input type="text" value="4"/>
Underdrawer Back Headboard	<input type="text" value="2"/>
FIXING KIT & INSTRUCTIONS	<input type="text" value="1"/>

## CUSTOMER CARE

We have checked all parts to ensure they are free of damage. However timber is a natural, living product. Occasionally timber can still be adjusting to humidity, for this reason a crack or stretch mark may appear after the product has been packaged.



Strictly Beds and Bunks however have a FREE PARTS REQUEST service in this unlikely event. You need to order a part please go to

Aftersales Portal - [www.strictlyaftersales.co.uk](http://www.strictlyaftersales.co.uk)  
Email Assistance: [help@strictlybedsandbunks.co.uk](mailto:help@strictlybedsandbunks.co.uk)



Place the drawer front face down on a carpeted floor. Important, the grooved edge must be facing you and at the bottom as per the picture.

Now get one of the sides, they are universal so any one will do. Again make sure the groove is at the bottom in line with the front of the drawer and facing INSIDE the drawer front.

Now using the black screws attach the two sides to the drawer front (left and right)



Once you have attached both the sides slide in the plywood base. Once the base is in attach the back using the BLACK screws provided.



Now we need to fix the castor wheels to each corner. Using the small screw L attach each corner wheel. You will only be able to attach 3 screws per corner. This is sufficient to hold in place.



## Note: END PANEL

Under drawers when purchased on there own do not come with an end panel. However if you have purchased a storage bed you will have an end panel. This is designed to go at the footboard end of the bed. The parcel will be marked E/P.

To fix this you simply loosen the two end corner posts. Push the end in from the end until fitting flush. Re-tighten the corner posts and attach the top of the end panel to the end facia board using 4x Black Screws